


Read this manual carefully before use, and retain it for future reference.

Product Overview



Illustrations of product, accessories, and user interface in the user manual are for reference purposes only. Actual product and functions may vary due to product enhancements.

Package Contents



Charging Case



Earphones



User Manual



Type-C
Charging Cable



Ear Tips

Instructions

Charging

- Charging the earphones

When the earphones are placed in the charging case, they will automatically start charging.

- Charging the charging case

Use the Type-C charging cable to charge the charging case, or place the charging case onto a compatible wireless charging pad with its indicator facing up to charge it. The charging indicator on the case is on while charging, and turns off once it is fully charged.

Checking Battery Level

- Checking the battery level of the earphones

After connecting the earphones to a phone, you can check the earphones' battery level on the phone's status bar.

Note: The phone's status bar always displays the battery level of the earphone with the lowest battery level. This feature is not supported by some phones.

- **Checking the battery level of the charging case**

Open the charging case's lid, or press the function button if the lid is closed:

1. When the charging case's indicator light stays lit for 5 seconds, it indicates the battery level is sufficient.
2. When the charging case's indicator light is blinking, it indicates its battery level is low and it should be charged immediately.

- **Checking the battery level by a Mi phone**

After successfully connecting to a phone, place the earphones into the charging case and close its lid. Make sure the Bluetooth function is enabled on your Mi phone. Hold your phone close to the charging case, then open the case's lid. A notification will appear on the phone, then you can check the battery level of the earphones and the charging case.

Note: When checking the battery level on your phone, please update your Mi phone to the latest stable version. This feature is currently only supported by some Mi phones.

Turning On

When opening the charging case, the earphones will automatically turn on.

Sleep Mode

Place the earphones back into the charging case and close the lid, the earphones will disconnect and go into sleep mode automatically.

Wearing

Take the earphones out of the charging case, and insert them into your ears according to the left (L) and right (R) marks.

Note: After using the earphones, place them back into the charging case. This will extend their lifespan and help you avoid losing or misplacing them.

Connecting

● Connecting the earphones to a new device

1. Place the earphones into the charging case, then press and hold the function button for 2 seconds. The charging case's indicator light will start blinking to indicate that the earphones are awaiting a connection.
2. Enable the device's Bluetooth, then locate and connect to "Mi Earphones 2 Pro". If a passcode is requested, enter "0000".

Note: Before using the earphones for the first time, please place them into the charging case and press and hold the function button for 5 seconds to activate them. Once activated, the earphones will automatically enter the awaiting connection state.

● Connecting the earphones with a Mi phone

Place the earphones into the charging case and close its lid. Make sure the Bluetooth function is enabled on your Mi phone. Hold your phone close to the charging case, then open the case's lid. Follow the on-screen instructions of the phone to connect to the earphones.

Note: The feature of quick connection is currently only supported by some Mi phones, please update your Mi phone to the latest stable version.

- Connection interrupted

When your device is out of wireless range of the earphones or its Bluetooth function is disabled, the earphones will automatically enter the awaiting connection mode. If the earphones are not connected to any device within five minutes, they will enter sleep mode.

- Automatic connection

When the earphones are in the charging case, opening the lid of the charging case will automatically connect the earphones to the most recently used Bluetooth device. If the earphones are not connected to any device within five minutes, they will enter sleep mode.


Note: If the earphones cannot automatically connect to a device, you will need to manually connect the earphones to the desired device via the device's Bluetooth settings.

- Clearing connection history

1. Place the earphones into the charging case.
2. Press and hold the charging case's function button for at least 10 seconds, and release it once the charging case's indicator lights up.

The earphones have been reset, the old connection history has been cleared, the charging case's indicator blinks, and the earphones are in pairing mode again.

Due to the connection characteristics of the Bluetooth signal, in dense environments with 2.4 GHz electromagnetic signal interferences, there may be occasional disconnects or no sound.



Incoming calls

Gently tap either one of the earphones twice: Answer/End calls

Music and voice assistant

While wearing both earphones:

Gently tap the right (R) earphone twice: Play/Pause music

Gently tap the left (L) earphone twice: Wake up the voice assistant

Press and hold either one of the earphones: Cycle through the

Noise cancellation on > Transparency mode > Wind noise

cancellation > Noise cancellation off

Taking out an earphone: Pause music

While wearing one earphone:

Gently tap the earphone twice: Play/Pause music

Notes:

1. The voice assistant function can be used only if your device supports it, and this function needs to be granted permission on the device.
2. When only using the left earphone, place the right earphone into the charging case and close the lid.
3. The noise cancellation mode is not available in single earphone mode.
4. The wind noise cancellation mode reduces the effects of wind noise during noise cancellation.

Specifications

Name: Wireless Earphones

Model: TWSEJ10WM Net Weight: 58 g Charging Port: Type-C Impedance: 32 Ω

Earphone Input: 5 V \approx 0.11 A Charging Case Input: 5 V \approx 1 A

Charging Case Output: 5 V \approx 0.25 A Wireless Connectivity: Bluetooth 5.0

Bluetooth Profiles: BLE/HFP/A2DP/AVRCP Supported Audio Codecs: SBC/AAC

Wireless Range: 10 m (open space without obstacles)

Charging Time: Approx. 1 h (using wired charging)

Earphone Battery Life: Approx. 6 h (while active noise cancellation is disabled)

Total Battery Life (with charging case): Approx. 30 h

Bluetooth Operation Frequency: 2402–2480 MHz (for EU)

Maximum Transmit Power for BT: < 13 dBm (for EU)


Maximum Transmit Power for BLE: < 13 dBm (for EU)

Wireless Charging Operating Frequency: 110–205 kHz

Storage Temperature: -20 $^{\circ}$ C to 45 $^{\circ}$ C Storage Humidity: 5%–95% RH

WEEE Information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste  equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

CE Hereby, Tiinlab declares that the radio equipment type TWSEJ10WM is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <http://www.mi.com/global/service/support/declaration.html>

WARNING: To avoid risk of fire, please just connect the product to a power supply of which output complies with requirements of PS1 defined in IEC/EN/UL 62368 standards (output capability is less than 15W).

Safety Caution

- Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like.
- Replacement of a battery with an incorrect type that can defeat a safeguard (such as catching fire, explosion, leakage of corrosive electrolyte etc).
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.
- The product operation maximum ambient temperature is 40°C.



To prevent possible hearing damage, do not listen at high volume levels for long periods.



The symbol indicates DC voltage

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Xiaomi Inc. is under license. Other trademarks and trade names are those of their respective owners.

The Qi logo is a trademark of the Wireless Power Consortium.

Manufactured for: Xiaomi Communications Co., Ltd.

Manufactured by: Tiinlab Corporation

(a Mi Ecosystem company)

Address:

No. 3333, Liuxian Avenue, Tower A, 35th Floor, Tanglang City, Nanshan District, Shenzhen, China

For further information, please go to www.mi.com