
x100m1 Smart Air Purifier 4 Lite Filter User Manual



Removing the Packaging

Read this manual carefully before use, and retain it for future reference.

Please unpack the new filter before use.



Note: Illustrations of product, accessories, and user interface in the user manual are for reference purposes only. Actual product and functions may vary due to product enhancements.

Opening the Filter Compartment


Warning: Make sure the purifier is turned off and the power adapter is unplugged before replacing the filter.



Press and hold the release buttons with both of your hands, and lift up the upper compartment of the purifier.


Removing the Old Filter

Note: To avoid injuries, do not put your fingers between the upper and lower compartments when replacing the filter.



Remove the old filter upwards.

Installing the New Filter



Install the filter into the filter compartment, and then place back the upper compartment of the purifier.

Resetting the Filter



While the purifier is on standby, simultaneously press and hold the power button and the display on/off button on the back of the purifier for 7 seconds. Once the filter is successfully reset, the purifier will make two beeps. Notes:

• When the air quality indicator blinks red for 30 seconds, it is a reminder that the filter is exhausted.

 $\cdot\,$ It is recommended to replace the filter every 6 to 12 months.

 \cdot Please purchase genuine and compatible filters from official channels.

Precautions

The filter that contains activated carbon may give off odors after a period of normal use. It is recommended to put the filter in a place with good lighting and ventilation for a certain period of time, so as to improve the activity of activated carbon and restore its partial adsorption capacity. When the filter is exhausted, please follow the reminder on the purifier's display to replace it immediately.